



AP-1

- 1.0 Mount the relay and the AP-1 panel.
- 2.0 Connect the thin black GROUND wire from the relay to a "ground" terminal on the AP-1 fuse panel grounding strip.
- 3.0 Connect the heavy brown LOAD wire from the relay to the PWR stud on the AP-1.
- 4.0 Connect the heavy red BATTERY + wire to your battery (+) post.
- 5.0 Connect the thin ORANGE wire to a KEY-ON wire to operate the relay whenever the bike is in operation. For example, this maybe your running lamps.
- 6.0 Connect the heavy black BATTERY - wire between your battery (-) post and the GND stud on the AP-1
- 7.0 Test operation.

Centech
wiring

**AP-1-70R
70 Amp Relay Kit**

Centech, Inc.

July 5, 2005