STANDARD INSTALLATION

- 1. Remove the top cover from the AP-2 and mount the unit using screws through the four stainless steel mounting feet.
- 2. Attach a 12 gauge or heavier power wire between the <u>PWR</u> post and the current source (normally your battery (+) post or ignition switch) to feed fuses F1, F2 and F3. Use a fusible link or Maxi-Fuse at the battery post. Use the heavy duty ring terminal provided. Solder and heat shrink all connections. A second power wire can be attached to the <u>BAT</u> post to feed power to fuses F4 and F5.
- 3. Attach a 12 gauge or heavier ground wire between the <u>GND</u> post on the AP-2 and your battery (-) post or frame. Use the heavy duty ring terminal provided.
- 4.Attach all positive power wires from your appliances to the power output terminal strip. Note that fuses F1, F2 and F3 feed five outputs on the terminal strip while F4 and F5 feed three outputs. This is done by stripping off 1/8" of insulation from the wire and inserting the bare wire into the opening of the terminal strip. Use a small screwdriver to tighten the retaining screw above the wire in the terminal strip.
- 5. Attach all ground wires from your appliances to the ground terminal strip.
- 6. After wiring and testing of your circuits, re-install the top cover on the AP-2 fuse panel.

HINTS: Each terminal strip opening can accept up to a 12 gauge wire. Use the metal traces between the fuses and the terminal strip as a guide to indicate which fuse feeds which terminal strip opening. Any terminal on the "ground" terminal strip can be used with any fuse.

<u>WARNING:</u> The AP-2 can handle a maximum of 60 AMPERES. Select the proper fuses as required by your needs. Fuse ratings are selected by the wire size being protected. Thin wires need low amperage fuses while heavy wires can use heavier fuses. Use 3 to 7.5A with thin wires and up to 30 A for very heavy wires.

When using the Centech AP-130R relay with the AP-2, after mounting the AP-2, follow the AP-130 instructions to wire the fuse panel to the power relay.



